

ProTec Vin-upLift Serum

ProTec **Vin-upLift** Serum to visibly erase wrinkles within minutes. The active ingredient is **Vinuplift** which is a combination of Swiss Ice wine and Tara Gum which instantly and significantly smoothes wrinkles and crow's feet. It also has a long term moisturising benefit.

	Trade Name	INCI Name	Function	%W/W	Supplier
1	Purified Water	Aqua	Solvent	87.9	
2	Vin-upLift	Wine (and) Caesalpinia Spinosa Gum (and) Maltodextrin (and) Aqua / Water	Active Ingredient	1	Mibelle Via ProTec Ingredia
3	Sisterna SP70-C	Sucrose Stearate	Emulsifier	2	Sisterna B.V.
4	Sisterna SP30-C	Sucrose Distearate	Emulsifier	1	Sisterna B.V.
5	CORUM 5047	Octyldodecyl Stearoyl. Stearate	Emollient	3	Corum INC via Protec Ingredia
6	Eutanol® G	Octyldodecanol	Emollient	1.5	BASF
7	Oat Lipid	Avena Sativa Kernel Oil	Emollient	1	Oat Cosmetics Via ProTec Ingredia
8	Lanette 18	Stearyl Alcohol	Co-emulsifier	1.5	BASF
9	Euxyl® PE 9010	Phenoxyethanol, Ethylhexylglycerin	Preservative	1.1	Shulke UK
				100	

ProTec Ingredia Ltd.

Unit 10 Delta Court, Manor Way, Borehamwood, Herts., WD6 1FJ, UK

Website: www.protectingredia.com

Registered in London No. 07517784 VAT No. GB 100 2120 14

The information provided, to the best of our knowledge is believed to be correct however we do not guarantee its accuracy. Potential purchasers shall not only rely on information stated herein when purchasing any products and should make their own investigations to determine if such products are suitable for a particular use. It is your responsibility to thoroughly test any formulations and all warranties, indemnities or liabilities implied or expressed by law are hereby excluded by ProTec Ingredia Ltd to the fullest extent permitted by law.

Method of Manufacture

Into the main vessel add:

Purified Water (1) Start the mixer on a fast speed.

Vin-upLift Mix until dissolved. The product will thicken up as the granules dissolve.

When the Vinuplift has dissolved and a smooth homogenous gel has formed into the main vessel add:

Sisterna SP70-C Mix until dispersed. Commence heating to 70-75C.

Sisterna SP30-C Mix until dispersed.

Euxyl® PE 9010 Mix until dispersed.

Into premix vessel add:

CORUM 5047 Commence heating to 70-75C.

Eutanol® G

Oat Lipid

Lanette 18

When both vessels are at 75C-80C add the premix into the main vessel & homogenize for 5 minutes.

Commence cooling to 23C.

Start the mixer on a moderate speed.

Adjust the mixer speed accordingly to ensure adequate batch turn over, avoiding aeration.

When the product is at 23C Check the product specifications.

Product Specifications

pH 5.00-6.00

Viscosity 8,000-15,000 cps RVT TBAR E, Speed 2.5 for 1 minute.

Colour Off White

Appearance Viscous, mobile liquid emulsion.

ProTec Ingredia Ltd.

Unit 10 Delta Court, Manor Way, Borehamwood, Herts., WD6 1FJ, UK

Website: www.protectingredia.com

Registered in London No. 07517784 VAT No. GB 100 2120 14

The information provided, to the best of our knowledge is believed to be correct however we do not guarantee its accuracy. Potential purchasers shall not only rely on information stated herein when purchasing any products and should make their own investigations to determine if such products are suitable for a particular use. It is your responsibility to thoroughly test any formulations and all warranties, indemnities or liabilities implied or expressed by law are hereby excluded by ProTec Ingredia Ltd to the fullest extent permitted by law.